

## 25mm Wood Venetian Blind Installation Instruction

This blind is supplied complete with universal brackets and a colour co-ordinated pelmet and bottom rail.

### Recess Fitting

The top of the reveal must be 35mm deep to accommodate this blind, and must be free from any obstruction. Suitable masonry plugs and screws must be used in order to firmly secure the brackets which can be face or top fixed through the pre-formed holes in the brackets.

Each bracket must be installed with two suitable masonry plugs and screws.

Place the blind in the area in which it is to be fitted and mark the position of each ladder lace which supports the slats and then position and fit each bracket approximately 40mm to the left or right of the marked positions, ensuring that the bracket will not obstruct any moving parts of the blind.

Fit one bracket per ladder lace, and make sure that they are all straight and in line. Brackets should be fitted at a sufficient distance from the window so that when the blind is installed it will clear window handles and other obstructions.

### Step 2

With the latch of the bracket in an open position, locate the front inside lip of the headrail into the front lips of the bracket. After pushing the head rail firmly into the brackets, close the latch of the brackets in the opposite direction, which now will ensure that the latch is now flush with the front of the headrail. When the latches have been securely closed and locked in position, peel the white protective layers of 3M tape of both the pelmet and headrail, and firmly press the pelmet against the headrail after lining the 3M tape of both the pelmet and headrail. Check that the blind is firmly retained in the brackets before operating the blind.

### Face Fixing

All of the above needs to be observed, except that the blind has now been installed on the outside of the window opening, and that the pelmet will now have fixed return ends ( if ordered) which will conceal the complete headrail at both sides.

### Operating Instructions

#### Raising:

With slats fully open, draw the cords vertically downwards until the desired height is reached, then incline cords slightly outwards to lock in position.

#### Lowering:

Pull cords towards the centre of the blind to disengage the cord lock and release gently through the hand until drop required is reached. Lock cords as in raising.

#### Tilting:

In each hand, hold the open ended cords and slowly pull in a downward direction on one of the cords, this will now tilt the angle of the slats. By pulling the other cord in a downward direction, the angle of the slats will now move in the reverse direction.

**Contact Details:** Tel: 031 579 2670  
Fax: 031 579 2680  
Email: [orders@ventolite.co.za](mailto:orders@ventolite.co.za)  
Web: [www.ventolite.co.za](http://www.ventolite.co.za)

**Address:** Ventolite Blinds CC  
Unit 19 Springriver Park  
48 Ebonyfield Avenue  
Springfield Park  
Durban