

Koin Roller Blind Installation Instruction

Your Koin side control roller blind is supplied complete with either top or face fix installation brackets.

Placement Of Brackets

A bracket must be fitted 50mm from either end of the blind, whilst the other brackets should be evenly spaced between these brackets.

Inside Window - recess installation

The top of the reveal must be 50mm deep to accommodate this blind, and must be free from any obstruction. Suitable masonry plugs and screws must be used in order to properly secure the brackets which can be top or face fixed through the pre-formed holes in the brackets.

Outside Window - face fix installation

Measure the blind allowing for equal overlap of the blind material on either side and then position the brackets over the window at the desired height and fix. Suitable masonry plugs and screws must be used in order to properly secure the brackets.

Operating Instructions

The chain control will have a stopper near the gear control, and one near the bottom of the chain.

To lower the blind, pull the chain until the stopper is almost at the gear unit, and the same applies when lifting. Do not attempt to over pull and force the stopper into the gear unit as this will damage the blind.

Contact Details: Tel: 031 579 2670
Fax: 031 579 2680
Email: orders@ventolite.co.za
Web: www.ventolite.co.za

Address: Ventolite Blinds CC
Unit 19 Springriver Park
48 Ebonyfield Avenue
Springfield Park
Durban