



**Blinds CC**

*Perfect Sun Control*

### Vertical Blind Installation Instruction

Depending on the mode of installation, this blind will be supplied with either top or face fix brackets together with the vertical headrail and blades.

#### Recess Fitting

The top of the reveal must be 90mm deep for 127mm wide blades or 70mm deep for 90mm wide blades. Fix through the clips provided with suitable masonry plugs and screws, so that the centre line of the blind headrail is 70mm from any obstruction ( 50mm for 90mm width blades).

#### Face Fixing

Use the face fix bracket provided, and fit to the wall by using suitable masonry plugs and screws.

#### Placement Of Brackets

A bracket must be fitted 100mm away from either end, whilst the other brackets should be evenly spaced between these brackets.

#### Hanging Of Blades

Once the headrail has been clipped into position, then carefully unwrap the blades and gently start clipping the blades from the control end into the runners. The rectangular opening of the slat-holder which is stitched in at the top of the blade should be gently pushed up vertically towards the runner

until the slat-holder slips over and rests on the small edged surface provided by the runner.

*Please ensure that the runners are tilted to an open position and that the blades are fixed in the order supplied.*

#### Operating Instructions

##### Tilting:

To rotate the blades to obtain optimum shading or privacy whilst retaining the view, pull gently on one of the beaded chains until the desired effect is obtained. Should one of the blades become miss-aligned, ensure that none of the blades are trapped or overlapping another blade on the wrong

side, and then pull the chains firmly in one direction and then the other. The blades should now work in perfect synchronisation.

##### Traversing:

To traverse the blades to one side, hold both cords in the hands and gently pull one cord to move the blades in the desired direction. *Please rotate the blades to the open position before operating.*

**Contact Details:** Tel: 031 579 2670  
Fax: 031 579 2680  
Email: [orders@ventolite.co.za](mailto:orders@ventolite.co.za)  
Web: [www.ventolite.co.za](http://www.ventolite.co.za)

**Address:** Ventolite Blinds CC  
Unit 19 Springriver Park  
48 Ebonyfield Avenue  
Springfield Park  
Durban