



Woven Wood Blind Installation Instruction

This bamboo blind is supplied complete with a cleat and universal installation brackets which can be top or face fixed through the pre-formed holes in the brackets, and are supplied with 4mm x 50mm slotted screws with wing nuts. Each bracket must be installed with two suitable masonry plugs and screws

Recess Fitting

The top of the reveal must be 50mm deep (80mm if bracket is used) in order to accommodate this blind, and must be free from any obstruction. Suitable masonry plugs and screws must be used in order to firmly secure the brackets when fixing. Pre-drilled holes have been drilled in the wooden headrail in order to accommodate the 4mm x 50mm screws that are fastened to the bracket. (This must be remembered when positioning your brackets). Once the brackets are installed, line up the holes of the headrail with the screws on the brackets and gently push the headrail in an upwards position until the screws at the bottom of the headrail are visible, and then fasten all screws with the wing nuts provided.

The cleat must be fitted on the control side, and can be positioned at a height which is convenient to the operator. All excess cord must be wrapped around the cleat after the blind has been raised.

Face Fixing

All of the above needs to be observed, except that the blind has now been installed on the outside of the window opening.

Operating Instructions

Raising:

Draw the cords vertically downwards until the desired height is reached, then incline cords slightly outwards to lock cords in position.

Lowering:

Pull cords towards the centre of the blind to disengage the cord lock and release gently through the hand until drop required is reached. Lock cords as in raising.

Contact Details: Tel: 031 579 2670
Fax: 031 579 2680
Email: orders@ventolite.co.za
Web: www.ventolite.co.za

Address: Ventolite Blinds CC
Unit 19 Springriver Park
48 Ebonyfield Avenue
Springfield Park
Durban