

VERTICAL BLINDS

Ventolite "Vertical" blinds are available in 90mm and 127mm blade widths.

All Vertical blinds allow you to regulate light and shading. Vertical blinds offer the clear advantage of allowing in light and scenery just by tilting the slats without having to draw the blind open.

Due to the nature of the 'Vertical' blind the following needs to be accepted and regarded as the norm.

1. Shade variations

The following must also be considered when selling this product:

1. Must not be sold as a "block-out" blind
2. Must not be sold as a privacy blind
3. Fading is to be expected – especially the side facing the sun

General:

1. Cut-outs – please provide detailed drawing
2. Please specify if there will be more than one blind in an opening
3. All blinds are supplied with either top or face fix installation brackets
4. Vertical blades can be opened towards the left, right, centre or split
5. All blades are ultrasonically welded
6. If blinds are recess fitted, then gaps are to be expected

Surcharges: - See Price Lists

1. Face fix installation brackets
2. Extension installation brackets
3. Alternating colours

Maximum recommended sizes:

90mm
Width – 3630mm
Drop - 3000mm

127mm
Width – 5001mm
Drop - 3000mm

Maximum m² area:

90mm - 10.89m²
127mm - 15m²

Minimum recess recommended for installation:

90mm blade width – 70mm
127mm blade width – 90mm

Contact Details: Tel: 031 579 2670
Fax: 031 579 2680
Email: orders@ventolite.co.za
Web: www.ventolite.co.za

Address: Ventolite Blinds CC
Unit 19 Springriver Park
48 Ebonyfield Avenue
Springfield Park
Durban

Ventolite Blinds CC *Perfect Sun Control*

Operating Instructions:

Tilting

To rotate the blades to obtain optimum shading or privacy whilst retaining the view, pull gently on one of the beaded chains until the desired effect is obtained. Should one of the blades become miss-aligned, ensure that none of the blades are trapped or overlapping another blade on the wrong side, and then pull the chains firmly in one direction and then the other. The blades should now work in perfect synchronization.

Never draw blade when in a closed position.

Traversing

To traverse the blades to one side, hold both cords in the hands and gently pull one cord to move the blades in the desired direction. *Please rotate the blades to the open position before operating.*

Cleaning:

Clean by vacuuming or wiping with a clean damp cloth for "Blackout" materials

Contact Details: Tel: 031 579 2670
Fax: 031 579 2680
Email: orders@ventolite.co.za
Web: www.ventolite.co.za

Address: Ventolite Blinds CC
Unit 19 Springriver Park
48 Ebonyfield Avenue
Springfield Park
Durban